



You might use a classical Xtal or a Low Power oscillator chip here.
In the case of using an oscillator chip, connect its output to the OSI and leave OSO open.



Date: 19.04.2021 10:57:26

TITLE: Pulsar P3 Loki Mod

Sheet: 1/1