

# **IB Physics Topic B4 Thermodynamics; SL & HL**

By timthedev07, M25 Cohort

# Table of Contents

<b>1</b>	<b>System and Surroundings</b>	<b>1</b>
<b>2</b>	<b>First Law of Thermodynamics</b>	<b>2</b>
2.1	Piston – Common Scenario Analysis . . . . .	3
<b>3</b>	<b>Pressure-Volume Graphs</b>	<b>4</b>
3.1	Graphical Interpretation . . . . .	4
<b>4</b>	<b>Types of Changes in a Gas</b>	<b>5</b>
4.1	Isobaric Change . . . . .	5
4.2	Isovolumetric Change . . . . .	6
4.3	Isothermal Change . . . . .	6
4.4	Adiabatic Change . . . . .	7
4.5	Combining Different Types of Changes . . . . .	8
<b>5</b>	<b>Heat Cycle and Engines</b>	<b>10</b>
5.1	The Carnot Cycle . . . . .	11
5.1.1	Efficiency . . . . .	13
5.2	Refrigerators and Heat Pumps . . . . .	14
5.2.1	Refrigerators . . . . .	15
5.3	Heat Pumps . . . . .	17
<b>6</b>	<b>The Second Law of Thermodynamics</b>	<b>18</b>
<b>7</b>	<b>Entropy</b>	<b>19</b>
7.1	A Macroscopic Interpretation . . . . .	19
7.1.1	Entropy for Irreversible Changes . . . . .	20
7.2	A Microscopic Interpretation . . . . .	21
7.2.1	Alternative Definition . . . . .	22
7.3	Microstate vs. Macrostate . . . . .	23

<b>8 Exam Questions</b>	<b>24</b>
8.1 Identifying Processes . . . . .	24
8.2 Microstate Calculations . . . . .	24
8.3 Entropy and Irreversible Processes . . . . .	25
8.4 Microstate Calculations (2) . . . . .	26
8.5 May 2019 Paper 3 TZ1 HL Question 9 . . . . .	28

# 1 System and Surroundings

Definitions:

- **System:** A system is a portion of the universe that has been chosen for study. Put simply, it is a set of objects to be analyzed. Conversely, the universe is a system that is made up of sub-systems within it.
  1. A **closed system** is one that **does not exchange matter** with its surroundings.  
I.e. the quantity of matter in the system is constant.
  2. An **isolated system** has even stricter requirements — it is one where **neither mass nor energy** can be exchanged with the surroundings.
- In contrast, the **surroundings** are everything external to the system that may also interact with it.

## 2 First Law of Thermodynamics

### Law. 1

$$Q = \Delta U + W \quad (1)$$

- $\Delta U$  is the change in internal energy of the system.
- $Q$  is the energy supplied to the system.
- $W$  is the work done by the system.

By the **Clausius sign convention**:

1.  $Q > 0$  when energy is transferred to the system, and vice versa.
2.  $\Delta U > 0$  when the internal energy of the system increases, and vice versa.
3.  $W > 0$  when work is done by the system **on the surroundings**, and vice versa.

This is a result of energy conservation. The **internal energy of a system changes** when:

1. The system does work, or work has been done on the system.
2. Energy is transferred to or from the system when there are temperature differences between the system and the surroundings.

An example of a measure of the internal energy of a system is the temperature of an ideal gas.

## 2.1 Piston – Common Scenario Analysis

The three quantities in [Equation \(1\)](#) in this particular system are

- $\Delta U$ : The **change in temperature**, and this can be converted using the temperature equation under section 4.3 (ideal gas kinetic model) in B3.
- $Q$ : Any thermal energy supplied to the gas, or inversely, the thermal energy lost by the gas.
- $W$ : The work done by the gas on the piston (e.g. when the gas expands to push the piston), or the work done on the gas by the piston (e.g. when the gas is compressed).

### 3 Pressure-Volume Graphs

Consider the following situation

- The system consists of an **ideal gas** in a cylinder with a movable piston.
- We assume, for the sake of simplicity, that the gas is kept at a **constant pressure**.

This of course requires energy to be somehow transferred from the surroundings to the gas. Analogously, there is a positive  $Q$ .

As the gas expands, the following occurs:

1. The volume of the gas increases.
2. The expansion pushes the piston upwards, doing work on the surroundings. Thus, there is a positive  $W$ .

This work done is given as

$$W = P\Delta V > 0 \quad (2)$$

*Proof.* Let  $\Delta x$  be the distance moved by the piston. Then, the work done is given as  $F\Delta x$ . Since  $F = PA$ , where  $A$  is the area of the piston, we have  $W = PA\Delta x$ . Notice that  $A\Delta x = \Delta V$ , so  $W = P\Delta V$ .  $\square$

#### 3.1 Graphical Interpretation




Figure 1: Pressure-Volume Graph

- The area under the graph represents the work done by the gas.
- The work done is positive when the gas expands, and negative when the gas is compressed. Use the arrow to verify this.
- **Make sure that the axes start at 0;** otherwise, in the case of a false origin, add in the missing bit.

## 4 Types of Changes in a Gas

“Iso” is a word of greek origin that means “same”.




Figure 2: Isovolumetric Change




Figure 3: Isothermal Change




Figure 4: Adiabatic Change

### 4.1 Isobaric Change

A change in a gas carried out at **constant pressure** throughout.

The gas law that applies in this case, is the **Charle’s Law**, i.e.  $\frac{V}{T} = \text{constant}$ .

On a P-V graph, this is represented by a horizontal line (see [Figure 1](#)).

Note also, that [Equation \(1\)](#) can be rewritten as

$$\Delta U = Q - P\Delta V$$



## 4.2 Isovolumetric Change

A change in gas carried out at **constant volume** throughout.

The gas law that applies is **Gay-Lussac's Law**, i.e.  $\frac{P}{T} = \text{constant}$ .

On a P-V graph, this is represented by a vertical line (see [Figure 2](#)).

In this case, the first law is rewritten as

$$\begin{aligned}\Delta U &= Q - P\Delta V = Q - 0P = Q \\ \Delta U &= Q\end{aligned}$$

## 4.3 Isothermal Change

A change in gas carried out at **constant temperature** (and hence constant internal energy) throughout.

The gas law that applies is **Boyle's Law**, i.e.  $PV = \text{constant}$ .

On a P-V graph, this is represented by an **isothermal curve**. Each temperature has a different curve (see [Figure 3](#)). Each curve is referred to as an isotherm.

Since the internal energy goes through no change, we have  $\Delta U = 0$ . Thus, the first law is rewritten as

$$Q = W$$

1. The implication is that **all** the energy supplied to the gas is used to do work.
2. If  $Q, W > 0$ , then, the gas is **expanding**, and energy is supplied to the gas, and the gas does work on the surroundings.
3. If  $Q, W < 0$ , then, the gas is **compressed**, and energy is lost by the gas, and work is done on the gas by the surroundings.

Practically, isothermal changes are not possible:

1. Perfect isothermal changes would theoretically require infinite time, here's why
  - (a) This requires the pressure change to be **quasi-static** (meaning it happens in such small, incremental steps that the system remains in thermal equilibrium throughout).
  - (b) Each tiny change in volume must be **instantaneously counterbalanced** by an appropriate heat transfer to prevent a temperature drop.
  - (c) This will then **require each  $\Delta V$  to be infinitely small**, which would take infinite time for the entire process to take place.
2. A slow enough change can be considered near-isothermal.

## 4.4 Adiabatic Change

A change in gas carried out with **no energy transfer** between the system and the surroundings. I.e the system is **thermally isolated**. This is done through insulating the system.

In this case,  $Q = 0$ , and so  $\Delta U = -W$ . This actually encapsulates two physical situations. It's straightforward that the two quantities have matching magnitudes; let us see why they have opposite signs.

- **Gas compression:** The surrounding is doing work on the gas, and so  $W < 0$ . The gas is increasing in energy, and thus  $\Delta U > 0$ .
- **Gas expansion:** The gas is doing work on the surroundings, and so  $W > 0$ . The gas is losing energy, and thus  $\Delta U < 0$ .

We introduce a new equation that has not been seen before. This is specific to adiabatic changes:

$$PV^{\frac{5}{3}} = \text{constant} \quad \text{and} \quad TV^{\frac{2}{3}} = \text{constant} \quad (3)$$

Note that perfect adiabatic changes are also not practically feasible.

1. The system must be perfectly insulated, which is impossible.
2. Another important reason is that a perfect adiabatic change would allow no time for change to take place.
  - (a) The duration of the change must be **infinitely short** to prevent any heat loss through the boundaries of the system to the surroundings.
  - (b) Thus, for a perfect adiabatic change to take place, the time taken must be 0.
3. Again, rapid enough changes can approximate adiabatic changes.

## 4.5 Combining Different Types of Changes

There are many different ways in which the different types of changes can be combined.




Figure 5: Isobaric, isochoric, isothermal




Figure 6: Isothermal, adiabatic




Figure 7: Adiabatic, isochoric

A general strategy is to

1. For each change, **recognize the type**.
2. Then, consider **what is changing** and **what is constant** based on the type of change. Considering the area can help.
3. Where necessary, **invoke the associated gas laws**.

The table below summarizes the changes

Shape	Type	Constant	Gas Laws
Horizontal line	Isobaric	Pressure	Charles'
Vertical line	Isovolumetric	Volume	Gay-Lussac's
Isothermal curve	Isothermal	Temperature	Boyle's
Skipping between two isotherms	Adiabatic	Internal energy	Equation (3)

For any change, the equation

$$\frac{P_1 V_1}{T_1} = \frac{P_2 V_2}{T_2}$$

can be used to relate the initial and final states of the gas.

When the temperature changes, one can find the change in internal energy using the equation

$$\Delta U = \frac{3}{2} n R (T_2 - T_1)$$

## 5 Heat Cycle and Engines




Figure 8: Heat Engine

A **heat engine** is a device that converts **thermal energy into mechanical work**. It takes in heat from a high-temperature source, does work, and releases some wasteful heat to a low-temperature sink.

Simplified explanation of the mechanism:

1. The engine absorbs  $Q_1$  energy from the hotter reservoir.
2. In the process of doing work, the engine releases  $Q_2$  energy to the colder reservoir. This is because it is never 100% efficient.
3. The useful work produced by the engine is  $W = Q_1 - Q_2$ .

The efficiency of this process  $\eta$  is given by

$$\eta = \frac{Q_1 - Q_2}{Q_1} = 1 - \frac{Q_2}{Q_1} \quad (4)$$

## 5.1 The Carnot Cycle




Figure 9: Carnot cycle; area enclosed is work done by the gas

The Carnot cycle is a theoretical cycle that is the most efficient possible heat engine cycle. It consists of four stages, two isothermal and two adiabatic stages. The stages are as follows:

1. AB: Isothermal expansion as  $Q_h = Q_1$  is supplied by the hot reservoir.
2. BC: Adiabatic expansion as the gas continues to expand, and the temperature drops to the lower  $T_c$ . There is a drop in the internal energy of the system, and the gas does work on the surroundings.
3. CD: Isothermal compression as  $Q_c = Q_2 < 0$  is dumped to the cold reservoir. The surrounding is doing work on the gas.
4. DA: Adiabatic compression; the gas is compressed, and the temperature rises back to  $T_h$ , completely returning to its original state.

The Carnot cycle is reversible:

A *reversible process* is one in which a system can be returned to its previous state with only an extremely small change in the system or surroundings.

An alternative definition is

A *reversible process* operates continuously in **quasi-static state**.

This means that for a change to be reversible, it must have happened extremely slowly.

By way of illustration, consider the melting of ice:

1. Initial state: The ice and its surroundings are both at the same temperature,  $0^{\circ}\text{C}$ . There is no temperature difference between the ice and the environment, so they are in thermal equilibrium.
2. Slow heat transfer: We now very slowly supply a tiny bit of heat energy to the ice, just enough for a small fraction of the ice to melt. Because the temperature of both the ice and the surroundings is the same, this tiny heat input occurs without a significant temperature gradient, ensuring that the process remains reversible. The ice starts to melt, but only a very small part, and the system stays close to equilibrium the entire time.
3. Melting continues slowly: As we keep adding heat slowly, more ice melts. At each tiny step, we could reverse the process by removing the exact amount of heat we added. If we did this, the water would freeze back into ice. This reversibility means the system can return to its original state without any net change in entropy for the entire system (ice + surroundings).
4. End state: Eventually, the entire block of ice melts. The process was done slowly enough that we can consider it a reversible operation. If we reversed the process step-by-step (cooling the water slowly), the water would freeze back into ice, and there would be no leftover changes.

### 5.1.1 Efficiency

In practice, a perfect Carnot engine is not possible. However, one can achieve near-Carnot engines by maximizing efficiency.

The efficiency of the Carnot cycle is given by

$$\eta_{\text{Carnot}} = 1 - \frac{T_c}{T_h} = 1 - \frac{Q_c}{Q_h}$$

where the temperatures are in Kelvin.

To maximize the efficiency of the engine, one must maximize the temperature difference between the hot and cold reservoirs.



## 5.2 Refrigerators and Heat Pumps

As previously stated, an ideal heat engine is reversible. A diagram of the directions of energy transfer is shown below.




Figure 10: Reversed Carnot Cycle

1. Isothermal compression (NM): The gas is compressed at a high temperature; to keep the temperature constant, some **heat is released to the hotter reservoir**.
2. Adiabatic expansion (MP): The gas continues to expand, but now without exchanging heat with its surroundings. Thus, the gas cools as it expands. The temperature of the gas drops below the temperature of the cold reservoir.
3. Isothermal expansion (PO): The gas is now below the temperature of the cold reservoir. As the gas expands under constant temperature, it absorbs heat from the cold reservoir to maintain the temperature. **Heat is absorbed from the cold reservoir**.
4. Adiabatic compression (ON): The gas is compressed, and the temperature rises back to the original temperature.

The main difference between the Carnot cycle and the reversed Carnot cycle is that the former transfers thermal energy to mechanical work, while the latter transfers mechanical work to thermal energy.

### 5.2.1 Refrigerators

The coils of a refrigerator contain a liquid called the “refrigerant”. A good refrigerant has the following properties

- low boiling point
- high s.l.h. of evaporation
- low s.h.c. of liquid
- low vapor density
- easily liquefiable




Figure 11: Refrigerator

We can match each component in this system to those in the heat engine:

- The “gas” is the refrigerant.
- The “work” is done by the compressor and the expansion valve.
- The “cooler reservoir” is the internal heat exchange coil in the refrigerator; this provides the latent heat that will be extracted and ejected by the refrigerant.
- The “hotter reservoir” is the external heat exchange coil.

The workflow is as follows

1. The compressor raises the temperature of the refrigerant (currently a gas)
2. The refrigerant releases heat to the surroundings through the external coil.
3. It cools down and condenses into a liquid.
4. It then passes through the expansion valve, where it expands back into a gas using the latent heat from the internal coil.
5. This process cools the internal coil, and the cycle repeats.

### **5.3 Heat Pumps**

A heat pump follows the identical mechanism as a refrigerator, but with a different purpose. The goal of a heat pump is to, for example, transfer the heat from the outside of a house to the inside.

timthedevo7

## 6 The Second Law of Thermodynamics

### Law. 2

The second law of thermodynamics states that

heat cannot spontaneously (without external work done on the system)  
flow from a colder body to a hotter body.

An alternative definition is due to Kelvin and Planck:

Energy cannot be extracted from a hot object and transferred entirely  
into work.

The other claim as part of this law is that in an isolated system, the entropy spontaneously increases over time, and the system evolves toward a state of maximum entropy.

A consequence of this law is that the efficiency of a heat engine is always less than 100%, or equivalently, the rejected (dumped) energy  $Q_c$  is always greater than 0.

## 7 Entropy

Entropy is a measure of the disorder of a system and it quantifies the amount of energy in a system that is not available to do work.

### 7.1 A Macroscopic Interpretation

On a macroscopic level, the change in entropy ( $\text{J K}^{-1}$ ) for a reversible change in a system is defined as

$$\Delta S = \frac{\Delta Q}{T} \quad (5)$$

where  $\Delta Q$  is the heat supplied to the system, and  $T$  is the temperature of the system at which the change occurs. This means that

- If energy is removed from the system  $\Delta Q < 0$ , then  $\Delta S < 0$ , i.e. the entropy decreases. However, whenever something happens, there can only be more disorder created than order (so entropy must increase), hence, this drop in entropy in this specific place is compensated by a greater increase in entropy somewhere else. This leads to the conclusion that **the entropy of a non-isolated system can only decrease if the entropy of the surroundings increases.**
- If energy is added to the system  $\Delta Q > 0$ , then  $\Delta S > 0$ , i.e. the entropy increases.

Consider a reversible action  $A \rightarrow B$

- One can calculate the entropy change using [Equation \(5\)](#)
- The total entropy change for a cycle is 0. This means that  $A \rightarrow B \rightarrow A$  has a total entropy change of 0.

For a thermodynamic process, the entropy of the universe never decreases during the process. It can remain the same – in fact, for a reversible change, the entropy of the surrounding remains unchanged due to the idealization and inexistence of disturbance of the surroundings.

### 7.1.1 Entropy for Irreversible Changes

The entropy change for an irreversible change, where heat flows from a hotter body to a colder body (the surroundings) is given by

$$\Delta S = \Delta Q \left( \frac{1}{T_{\text{surroundings}}} - \frac{1}{T_{\text{gas}}} \right) \quad (6)$$

This change results in an increase in the entropy, and this implies that the **entropy of the universe is always increasing**. This is another way of stating the second law of thermodynamics.

A key point to note about irreversible changes is that the final state has a greater number of microstates than the initial state.

## 7.2 A Microscopic Interpretation

This definition of entropy is based on the number of possible microstates of a system. Consider a system with  $\Omega$  different arrangements (a.k.a. **microstates**) of its particles, then, the entropy (**not the entropy change**) of these molecules is defined as

$$S(\Omega) = k_B \ln \Omega \quad (7)$$

Consider a substance that originally has a perfect fixed lattice structure.

1. Initially, there is just a single microstate, as the particles are all in a fixed position and cannot exchange positions with others to form new arrangements.
2. The entropy, in this case, is

$$S(1) = k_B \ln 1 = 0$$

3. Remove one atom from the lattice, now there are more than just one microstate. Denote the number of arrangements now as  $\Omega > 1$ .
4. The entropy in this case is

$$S(\Omega) = k_B \ln \Omega > 0$$

in fact, it would be a very large number.



**7.2.1 Alternative Definition**

Another definition is that the change in entropy arises from the energy  $\Delta Q$  that has been required to remove the atom from the lattice at temperature  $T$ . This also leads to

$$\Delta S = \frac{\Delta Q}{T}$$

### 7.3 Microstate vs. Macrostate

- A microstate is one unique arrangement of a system assuming that each entity in the system is distinguishable
- A macrostate is an arrangement of microstates which have an identical outcome when individuals are not treated as distinguishable.
- Consider a simplified scenario of a system of 10 counters, where each can be red or blue.
  - A macrostate in this case is the combination of the number of red counters and the number of blue counters. For example, if we denote  $(r, b)$  as the combination of numbers, then, a macrostate could be  $(3, 7)$ .
  - A microstate is the exact arrangement of the particles, e.g. rrrbbbbbbb is a microstate of the macrostate of  $(3, 7)$ .

## 8 Exam Questions

### 8.1 Identifying Processes




Figure 12: Cycle

- YZ is a **vertical line**, and so it is an **isovolumetric** process.
- Now, we know that an adiabatic change involves skipping from one isothermal to another and so an adiabatic curve should be steeper than an isothermal curve.

### 8.2 Microstate Calculations

In one throw the coins all land heads upwards. The following throw results in 7 heads and 3 tails. Calculate, in terms of  $k_B$ , the change in entropy between the two throws.

- The initial state has a single microstate, whereas the final state has  $\binom{10}{3}$  microstates.
- The initial entropy is

$$S(1) = k_B \ln 1 = 0$$

- The final entropy is

$$S\left(\binom{10}{3}\right) = k_B \ln \left(\binom{10}{3}\right)$$

- Then, the change in entropy is

$$\Delta S = k_B \ln \left(\binom{10}{3}\right) = 4.8k_B$$

### 8.3 Entropy and Irreversible Processes

The particles of an ideal gas initially occupy one half of an isolated container, whose second half is initially empty. The gas is then allowed to expand freely into the second half. The diagram shows two configurations of the gas: the initial configuration A and configuration B, in which equal numbers of particles occupy each half of the container.




Figure 13: Two configurations

When a particle moves to a new position within the same half of the container, the microstate of the gas is considered unchanged. When a particle moves to the other half of the container, a new microstate is formed.

(a) Explain why the gas in configuration B has a greater number of microstates than in A.

- Configuration A has only one microstate
- In configuration B, pairs of particles can be swapped between the halves
- Every such change gives rise to a new microstate so there is a larger number of microstates in B

(b) Deduce, with reference to entropy, that the expansion of the gas from the initial configuration A is irreversible.

- $S_A = k_B \ln \Omega_A$  and  $S_B = k_B \ln \Omega_B$
- Since  $\Omega_B > \Omega_A$ , the entropy in configuration B is greater
- A process that results in an increase of entropy in an isolated system is irreversible.

## 8.4 Microstate Calculations (2)

An isolated system consists of six particles. The total energy of the system is  $6E$ , where  $E$  is a constant. The particles can randomly exchange energy between one another, in integer multiples of  $E$ .




Figure 14: Energy Diagram

The energy diagram shows two possible configurations of the system. Each dot in the diagram represents one particle. In configuration A, one particle has energy  $6E$  and the remaining particles have zero energy. In configuration B, three particles have energies  $3E$ ,  $2E$  and  $E$ , and the remaining particles have zero energy.

(a) State and explain the number of microstates of the system in configuration A.

- 6 microstates
- Any of the six particles can be the one of the highest energy

(b) Configuration B has 120 microstates. Calculate the entropy difference between configurations B and A. State the answer in terms of  $k_B$ .

$$S_B - S_A = k_B(\ln 120 - \ln 6) = k_B \ln 20 \approx 3.0k_B$$

(c) The system is initially in configuration A. Comment, with reference to the second law of thermodynamics and your answer in (c), on the likely evolution of the system.

- The second law predicts that isolated systems spontaneously evolve towards high-entropy states.
- From (c), the entropy of B is greater than that of A.
- The final state will likely be similar to B / contain relatively many low-energy particles of different energies.

**8.5 May 2019 Paper 3 TZ1 HL Question 9**

- (a) Show that during an adiabatic expansion of an ideal monatomic gas the temperature  $T$  and volume  $V$  are given by.

$$TV^{\frac{2}{3}} = \text{constant}$$

Solution:

$d$