



General Notes

1. ADHESIVE TO BE EXTERIOR GRADE POLYURETHANE CONSTRUCTION ADHESIVE.
2. FINISH ALL WOOD COMPONENTS AND ASSEMBLIES WITH 2 COATS OF EXTERIOR SOLVENT BASED TRANSPARENT STAIN (BENJAMIN MOORE - MOORWOOD OR APPROVED EQUAL).
3. ALL FASTENERS TO BE STAINLESS STEEL UNLESS OTHERWISE NOTED.

Key Notes

- 1 FASTEN AND ADHERE BASE WITH 10X2.5 STAINLESS STEEL FLAT SOCKET HEAD WOOD SCREW AND #10 COUNTERSUNK FINISHING WASHER.
- 2 FASTEN AND ADHERE WOOD CORNER POST AND RIDGE WITH 6X1.5 STAINLESS STEEL FLAT SOCKET HEAD WOOD SCREW AND #8 COUNTERSUNK FINISHING WASHER.
- 3 6MM DIA ALUM DOME HEAD RIVETS WITH 6MM ALUM WASHERS
- 4 "BENDY" PLY PANELS: 6MM MAHOGANY "BENDY" PLY FROM 1219 X 2438 [4' X 8'] LONG GRAN SHEETS.
- 5 DIRECTION OF FACE GRAN
- 6 BASE PLATE ASSEMBLY: 38 X 286 [2 X 12] LUMBER, LAP AND ADHERE AND FASTEN WITH 8X2.5 SOCKET HEAD WOOD SCREWS
- 7 STAINLESS STEEL THREADED ROD
- 8 STAINLESS STEEL BOLT AND WASHER, COUNTERSINK INTO BASE PLATE ASSEMBLY AND PLUG WITH WOOD.
- 9 ROUND PLYWOOD PLATE, CUT TO FIT DIAMETER OF ICE HOLE, FINISH TO MATCH "BENDY" PLY
- 10 ICE HOLE: DRILL WITH ICE AUGER AND FLOOD WITH WATER AFTER INSTALLING ROUND PLYWOOD PLATE.
- 11 COUNTERSINK STAINLESS STEEL NUT AND WASHER INTO WOOD BASE PLATE ASSEMBLY
- 12 38X184 BLOCKING, MITER AS INDICATED
- 13 EXISTING ICE
- 14 LAP JOINT, FASTEN AND ADHERE AS INDICATED
- 15 BUTT JOINT, FASTEN WITH 6MM ALUM DOME HEAD RIVETS AND 6MM STAINLESS STEEL FENDER WASHERS
- 16 38 X 174 WOOD PLANKING, RP FROM 38 X 184 [2" X 8"] TO SQUARE EDGES, GLUE AND RESOUT JOIN PLANKS. SAND AND SMOOTH TOP FLUSH WITH WOOD BASE PLATE ASSEMBLY. ADHERE ALL JOINTS
- 17 GALVANIZED STEEL SHEET METAL STRAPPING AS REQUIRED, MIN THICKNESS 26 GAUGE
- 18 ROUND STAGGERED PERFORATION PATTERN WITH 6MM DIA HOLES AT 25MM OFFSETS. OFFSET PATTERN 25MM FROM EDGE AND ALIGN AS INDICATED
- 19 "BENDY" PLY PANEL AT INTERIOR FACE OF CORNER POST AND RIDGE BEAM. CUT TO SIZE, ADHERE AND FASTEN WITH 6X1.5 STAINLESS STEEL FLAT SOCKET HEAD WOOD SCREW. FINISH EDGE FLUSH WITH FACE OF BLOCKING
- 20 NOTCH BASE ASSEMBLY TO SUIT "BENDY" PLY PANELS
- 21 TAPER BASE TO SUIT "BENDY" PLY PANELS, REFER TO DETAILS 008 AND 009
- 22 38 X 38 WOOD BLOCKING. FINISH, FASTEN AND ADHERE AS INDICATED
- 23 8X1.5 STAINLESS STEEL FLAT SOCKET HEAD WOOD SCREW AND #10 COUNTERSUNK FINISHING WASHER.