

# INDEX OF FUNCTIONS

FUNCTIONS	PLATE NUMBERS
1 - 15	EARTH
16 - 21	NAVIGATION
22 - 23	PARKING DISTANCE CONTROL
24 - 25	AIR BAG AND SEAT BELT PRETENSIONER
26 - 27	ALARM AND IMMOBILISER
28	CIGARETTE LIGHTER
29	IMMOBILISER
30 - 37	ANTI-LOCK BRAKING SYSTEM
38 - 39	HORN
40	AUTOMATIC TRANSMISSION
41 - 42	SEQUENTIAL GEARBOX
43 - 44	PASSENGER COMPARTMENT INTER-CONNECTION UNIT
45 - 48	RAIN AND LIGHT SENSOR
49	ADDITIONAL PASSENGER COMPARTMENT HEATING
50 - 53	BASIC HEATING
54	BASIC HEATING OR AIR CONDITIONING
55 - 56	CHARGE CIRCUIT
57 - 58	STARTING CIRCUIT
59	INSTRUCTORS CONTROL UNIT
60	UNDER STEERING WHEEL CONTROL
61 - 63	AIR CONDITIONING COMPRESSOR
64 - 89	DOOR LOCKING
90 - 92	TAILGATE LOCKING
93 - 94	FUEL FILLER FLAP LOCKING
95 - 98	AIR CONDITIONING
99 - 102	AUTOMATIC AIR CONDITIONING
103 - 106	HEADLIGHT HEIGHT ADJUSTMENT
107 - 109	REAR WINDOW DE-ICING
110	HEATED REAR WINDOW AND REAR-VIEW MIRRORS
111 - 112	POWER ASSISTED STEERING
113 - 114	LUGGAGE COMPARTMENT LIGHTING
115 - 118	COURTESY LIGHTING
119 - 120	FLOOR LIGHTING
121 - 124	STORAGE COMPARTMENT LIGHTING
125 - 126	REAR SCREEN WIPER
127 - 130	WINDSCREEN WIPER
131 - 138	REAR FOGLIGHTS
139	FRONT FOGLIGHTS
140 - 144	REVERSING LIGHTS
145 - 146	DIPPED, MAIN BEAM AND POSITION LIGHTS
147 - 156	BRAKE LIGHTS
157 - 160	SPEAKERS
161 - 164	DIRECTION INDICATORS AND HAZARD WARNING LIGHTS
165 - 166	FUEL LEVEL INDICATOR
167	OIL LEVEL INDICATOR
168 - 171	EXTERNAL TEMPERATURE INDICATOR
172	ELECTRONIC INJECTION
173 - 184	ELECTRONIC INJECTION PASSENGER COMPARTMENT SECTION
185 - 199	ELECTRONIC INJECTION ENGINE SECTION

# INDEX OF FUNCTIONS

FUNCTIONS	PLATE NUMBERS
200	AFTER-SALES FRONT FOG LIGHT KIT
201	HEADLIGHT WASHERS
202	CARD READER AND STEERING COLUMN LOCK
203 - 204	DRIVER'S ELECTRIC WINDOW
205 - 206	REAR ELECTRIC WINDOWS
207 - 218	FRONT ELECTRIC WINDOWS
219 - 220	REAR ELECTRIC WINDOWS
221 - 233	FUSE AND RELAYS BOARD
234	ENGINE FUSE AND RELAY BOARD
235 - 236	DIESEL PRE AND POSTHEATING
237 - 238	DIAGNOSTICS SOCKET
239 - 244	RADIO AND COMMUNICATION SYSTEMS
245 - 251	ENGINE COOLING SYSTEM
252 - 253	SPEED REGULATOR
254 - 261	ELECTRIC REAR-VIEW MIRRORS
262	HEATED SEATS
263 - 266	INSTRUMENT PANEL
267	OIL PRESSURE WARNING LIGHT
268 - 269	BRAKE FLUID LEVEL WARNING LIGHT
270	THERMOPLUNGERS
271 - 278	ELECTRIC SUNROOF
279 - 283	UCH
284	UCH SECTION 1
285	UCH SECTION 2
286	ENGINE SWITCHING PROTECTION UNIT
287 - 290	KEYLESS VEHICLE AND HANDS-FREE ACCESS
291	VEHICLE SPEED