

Current Pattern: None Status: Stopped

Intensity: 3200 candela

Set Intensity...

4Hz

Continuous 4Hz signal, 50% duty cycle

4Hz Alt.

2-Color, 4Hz, 1-1 Alternating

4Hz Group/Int

4Hz 50% Duty cycle, 4-3 interrupt

4Hz Group/Alt

2-Color, 4Hz 50% duty cycle, 4-1

6Hz

Continuous 6Hz signal, 50% duty cycle

SOS A1-MOD

SOS-A1

Chirp-Up-MOD

2Hz/5, 4Hz/8, 6Hz/15

Chirp-Up-MOD-3

A: 2Hz/5, B: 4Hz/8, C: 6Hz/15

2Hz-25%

Continuous 2Hz 25% duty cycle

2Hz-50%

Continuous 2Hz signal, 50% duty cycle

2Hz-Group/Alt

2-Color, 2Hz 25% duty cycle, 4-3 alternating

2Hz-Dual

2-Color, 2Hz 50% duty cycle 4-4 alternating

Fixed

Continuous Signal

Presets


Preset Patterns

Current Pattern: None Status: Stopped

Intensity: 3200 candela

Set Intensity...

Pattern: 4Hz



Color 1...

None


Cancel

Current Pattern: None Status: Stopped

Intensity: 3200 candela

Set Intensity...

Pattern: 4Hz



When choosing color,
only color buttons
and Cancel are clickable

Color 1...

Red

Red-Orange

Cyan

Green

White

Blue

Yellow


Cancel

Current Pattern: None Status: Stopped

Intensity: 3200 candela

Set Intensity...

Pattern: 4Hz



Color 1...

Cyan

Start button appears when all
colors have been chosen

→ Start

Cancel

Current Pattern: 4Hz

Status: Running

⊠ Stop

Intensity: 3200 candela

Set Intensity...

4Hz

Continuous 4Hz signal, 50% duty cycle

4Hz Alt.

2-Color, 4Hz, 1-1 Alternating

4Hz Group/Int

4Hz 50% Duty cycle, 4-3 interrupt

4Hz Group/Alt

2-Color, 4Hz 50% duty cycle, 4-1

6Hz

Continuous 6Hz signal, 50% duty cycle

SOS A1-MOD

SOS-A1

Chirp-Up-MOD

2Hz/5, 4Hz/8, 6Hz/15

Chirp-Up-MOD-3

A: 2Hz/5, B: 4Hz/8, C: 6Hz/15

2Hz-25%

Continuous 2Hz 25% duty cycle

2Hz-50%

Continuous 2Hz signal, 50% duty cycle

2Hz-Group/Alt

2-Color, 2Hz 25% duty cycle, 4-3 alternating

2Hz-Dual

2-Color, 2Hz 50% duty cycle 4-4 alternating

Fixed

Continuous Signal

Presets

Preset Patterns

Current Pattern: 4Hz Status: Stopped

➔ Start

Intensity: 3200 candela

Set Intensity...

Intensity button will be disabled if a pattern is running

4Hz

Continuous 4Hz signal, 50% duty cycle

4Hz Alt.

2-Color, 4Hz, 1-1 Alternating

4Hz Group/int

4Hz 50% Duty cycle, 4-3 interrupt

4Hz Group/Alt

2-Color, 4Hz 50% duty cycle, 4-1

6Hz

Continuous 6Hz signal, 50% duty cycle

SOS A1-MOD

SOS-A1

Chirp-Up-MOD

2Hz/5, 4Hz/8, 6Hz/15

Chirp-Up-MOD-3

A: 2Hz/5, B: 4Hz/8, C: 6Hz/15

2Hz-25%

Continuous 2Hz 25% duty cycle

2Hz-50%

Continuous 2Hz signal, 50% duty cycle

2Hz-Group/Alt

2-Color, 2Hz 25% duty cycle, 4-3 alternating

2Hz-Dual

2-Color, 2Hz 50% duty cycle 4-4 alternating

Fixed

Continuous Signal

Presets

Preset Patterns

Current Pattern: 4Hz

Status: Stopped

Intensity: 3200 candela

Set Intensity...

Intensity Select (Candela)

400	800	1200
1600	2000	2400
2800	3200	3600
	4000	

Current Pattern: 4Hz

Status: Stopped

Intensity: 3200 candela

Set Intensity...

4Hz

Continuous 4Hz signal, 50% duty cycle

4Hz Alt.

2-Color, 4Hz, 1-1 Alternating

4Hz Group/Int

4Hz 50% Duty cycle, 4-3 interrupt

4Hz Group/Alt

2-Color, 4Hz 50% duty cycle, 4-1

6Hz

Continuous 6Hz signal, 50% duty cycle

SOS A1-MOD

SOS-A1

Chirp-Up-MOD

2Hz/5, 4Hz/8, 6Hz/15

Chirp-Up-MOD-3

A: 2Hz/5, B: 4Hz/8, C: 6Hz/15

2Hz-25%

Continuous 2Hz 25% duty cycle

2Hz-50%

Continuous 2Hz signal, 50% duty cycle

2Hz-Group/Alt

2-Color, 2Hz 25% duty cycle, 4-3 alternating

2Hz-Dual

2-Color, 2Hz 50% duty cycle 4-4 alternating

Fixed

Continuous Signal

Presets

Preset Patterns

Current Pattern: 4Hz

Status: Stopped

Intensity: 3200 candela

Set Intensity...

Tapping on a pattern button in this screen
will automatically start the pattern

4Hz

Red

6Hz

Green

4Hz

Yellow