


BE SURE TO SEAL THE TOP WITH A
PVC END CAP OR BALL VALVE



IF YOU ARE HAVING TROUBLE WITH DARTS
FEEDING, YOU CAN GRIND DOWN THIS NUB TO
MAKING THE LOADING PROCESS SMOOTHER.

DART

BARREL

1/2" PVC WYE

AIR

1/2" LENGTH 1/2" PVC

THE DART SITS IN THE HOPPER SYSTEM AS ABOVE. WHEN AIR IS
INTRODUCED, THE BOTTOM DART BENDS THROUGH THE HOPPER
AND IS SEATED ON THE FUNNEL PART OF THE BARREL, CREATING A
SEAL. THE REMAINING AIR THEN FORCES THE DART DOWN AND
OUT THE BARREL. THE NEXT DART WILL FALL INTO PLACE.