



2. Catch number game

During you press the touch sensor, the 4bit FND display will show you the increasing number. Who will catch the 2000 more closely?



Part List



X 2



X 3



X 3




X 1




(S) X 2




4bit FND display



Slide Dimmer




Melody Buzzer




Touch X 1

Catch number game



1




Touch X 1



X 1




X 1




2



X 1




3



X 1




(S) X 2



Assemble the small bolt at bottom


4




X 1




X 3



5




6



Slide Dimmer




X 1




7



4bit FND



Melody Buzzer





Connect to the main controller

