




Laser Scanner
Hokuyo UTM-30LX



Encoders: 360 counts/revolution
Encoder Order: FR FL RR RL
Encoder Direction: Forward motion = positive
Lidar 0-angle is forward, rotation is counterclockwise from -135 to 135 degrees



Units: mm