

Chapters

1 General
Information

2 Troubleshooting

3 Parts Lists

4 Removal &
Replacement
Procedures

5 Verification
Procedures

6 PM/Total
Service Call

VP-60: Decontamination

ABBOTT



Appendices

A Block Diagrams,
Boards, Pinouts

B Parameters
(Assay, System)

C ASTM Interface

D Software
Menu Maps

Shortcuts

IP List

Error Code List

RR List

VP List

Table of Contents

Index