


IP-75 Error codes 150, 151, 152, 153 (pg 1 of 3)

EC-150: Group 1 failed


EC-151: Group 2 failed

EC-152: Group 3 failed


EC-153: Group 4 failed



IP75-1.vsd



Chapter Contents	Manual Contents	CD Main Screen	Index
------------------	-----------------	----------------	-------



Replace Multivalve Block (RR-5.3),
then Motor Driver Bd (RR-8.5),
then Digital I/O Bd (RR-7.10).



Replace Pump Assy (RR-5.1),
Replace Motor Driver Bd (RR-8.5),
Replace Digital I/O Bd (RR-7.10).

IP75-3.vsd