

### PL-3: FRONT VIEW (pg 1 of 3)

Item	RR	Part No.	Description
1	3.1	3-47041-01	Fan and Gasket Assy
2	3.2	47005-102	Assy, Reagent Receiver/Heater Block
2a		3-04485-01	Reagent Heater Block
2b		3-47088-01	Assy, Reagent Receiver
3	3.3	3-31048-01	Carousel Motor/Sensor/Bracket
4	3.4	41606-104	Liquid Heater & Bracket Assy
5	3.5	LN 8B92-01	LCx® Analyzer Probe Assy
7		LN 9A42-14	Tubing, Interconnect Probe
8		47102-101	Flag, Z-Boom Home

Item	RR	Part No.	Description
9	3.9	3-47090-03	Boom Assy
10		3-31902-01	Filter, Fan
11		31127-103	Heater Baffle
12		3-31460-01	Insulator, Air Heater
13	3.13	31051-103	Thermistor Assy, Air
14		3-31031-01	Carousel Home Sensor Assy
15		3-44340-01	Cable, Air Heater/Thermistor
16	3.16	3-04521-01	Air Heater Assy

*Parts List items 17-21 listed on next page.  
Additional parts (not shown) listed on next page.  
PL-3 screws/washers table on next page.*


### PL-3: Front View (pg 2 of 3)

Item	RR	Part No.	Description
17		44021-103	Spacer, Fan Filter
18	3.18	3-47076-01	Carousel Receiver
19	3.19	47084-102 47104-103	Assy, Probe LLS Cable Clamp
20		3-47097-01	Probe Holder
21		31803-104	Baseplate

Additional part (not shown in illustration):  
44365-102 Probe Assy Thumb Nut

Item	Part No.	Description
S1	14490-169	Screw, PHP 6-32 x .250
S2	14990-199	Screw, PHP 8-32 x 2.00
S3	14494-206	Screw, PHP 8-32 x .375
S4	14494-106	Screw, PHP 6-32 x .380
S5	14494-205	Screw, PHPM 8-32 x .312
S6	14490-184	Screw, PHP 8-32 x .562
S7	10842-310	Screw, Pan 4-40 x .375
S8	14494-005	Screw, PHP 4-40 x .316

### PL-3: Front View (pg 3 of 3)



PL-3.ds4

### 3 Parts Lists

LCx<sup>®</sup> Analyzer Service Manual (Text P/N 47278-102)

### PL-3: Front View

**3 - 13**

Block/board diagrams	PL-3 parts list		Chapter Contents	Manual Contents	CD Main Screen	Index
----------------------	-----------------	--	------------------	-----------------	----------------	-------