

To bring router back to default factory settings

Commands to be entered via router monitor mode (rommon)

```
rommon 2 > confreg  
0x2142
```

```
rommon 3 > reset
```