

## Specification

Model	GA200-06	GA200-08	GA300-08	GA300-10	GA400-10	GA400-15	GA600-20	GA600-25
Fluid	Air							
Port size	1/8"	1/4"	1/4"	3/8"	3/8"	1/2"	3/4"	1"
Way number	Four							
Pressure range	0-0.9MPa(0-130Psi)							
Proof pressure	1.5MPa(215Psi)							
Temperature range	-20~70°C							

## Ordering Code

MGA214			—	08	—	G
Model				Port size		Thread
GA200: 200 Series gas-distribution block				06: 1/8"		G: G
GA300: 300 Series gas-distribution block				08: 1/4"		P: PT
GA400: 400 Series gas-distribution block				10: 3/8"		
GA600: 600 Series gas-distribution block				15: 1/2"		
				20: 3/4"		
				25: 1"		




Note: When it is used with F.R.L. combination, extra mounting bracket is need. Please refer to below for order detail.

## Dimensions





Model/Item		A	B	C	D
GA200	06	1/8"	36	30	28.5
	08	1/4"	36	30	28.5
GA300	08	1/4"	44	38	35
	10	3/8"	44	38	35
GA400	10	3/8"	52	52	42
	15	1/2"	52	52	42
GA600	20	3/4"	76	68	60
	25	1"	76	68	60

## Joint accessories—Bracket

## How to Select the Bracket

Bracket name	Code	Photo	Adapt accessories model		
T shape bracket	GA200T-P1		GV200	GZ200	GA200
	GA300T-P1		GV300	GZ300	GA300
	GA400T-P1		GV400	GZ400	GA400
	GA600T-P1		—	—	GA600
L shape bracket	GA200L-P1		GV200	GZ200	GA200
	GA300L-P1		GV300	GZ300	GA300
	GA400L-P1		GV400	GZ400	GA400
	GA600L-P1		—	—	GA600
U shape bracket	GA200U-P1		GV200	GZ200	GA200
	GA300U-P1		GV300	GZ300	GA300
	GA400U-P1		GV400	GZ400	GA400
	GA600U-P1		—	—	GA600

## How to Use the Bracket

Use to joint GV and GC series	Use to joint GZ and GC series	Use to joint GA and GC series	Use to joint GZ GV and GC series
			

AUG12/RW/A