

GNU Radio Lab 1: FM Broadcasting & WiFi Signals

EE 451: Communications Systems

Name: _____ Date: _____

Objectives

1. Use RTL-SDR to receive and demodulate FM broadcast signals
 2. Understand frequency deviation and audio bandwidth in FM
 3. Observe WiFi signals in the 2.4 GHz spectrum
 4. Analyze real-world RF spectrum characteristics
 5. Build GNU Radio flowgraphs for signal reception
-

Equipment Required

- Computer with GNU Radio Companion installed
 - RTL-SDR USB dongle
 - Antenna (included with RTL-SDR)
-

Part 1: RTL-SDR Setup and Verification (15 points)

Task 1.1: Verify RTL-SDR Connection

1. Connect the RTL-SDR dongle to your computer
2. Open a terminal and run:

```
rtl_test
```

3. Verify the dongle is detected

Screenshot 1.1: Paste a screenshot of successful `rtl_test` output here.

[Insert screenshot]

Task 1.2: Launch GNU Radio Companion

1. Open GNU Radio Companion:

```
gnuradio-companion
```
2. Create a new flowgraph
3. Add the following blocks:
 - **RTL-SDR Source** (from `osmocom` category)
 - **QT GUI Frequency Sink**
 - **QT GUI Waterfall Sink**
4. Configure the RTL-SDR Source:

- Sample Rate: 2.4 MHz (2400000)
- Center Frequency: 100 MHz (for FM band)
- RF Gain: 40 dB
- IF Gain: 20 dB

5. Connect the source to both sinks

Screenshot 1.2: Paste a screenshot of your flowgraph here.

[Insert screenshot]

Question 1.1 (5 points)

- What is the frequency range of the RTL-SDR dongle you're using?
- What is the maximum sample rate supported?

Your Answer:

[Write your answer here]

Part 2: FM Broadcast Reception (30 points)

Task 2.1: Build FM Receiver Flowgraph

Create a flowgraph with the following blocks:

1. RTL-SDR Source

- Sample Rate: 2.4 MHz
- Center Frequency: [Your local FM station, e.g., 91.5 MHz]
- Gains: Adjust as needed

2. Low Pass Filter

- Cutoff Frequency: 100 kHz
- Transition Width: 10 kHz
- Decimation: 10

3. WBFM Receive (Wideband FM demodulator)

- Quadrature Rate: 240 kHz (after decimation)
- Audio Decimation: 5

4. Rational Resampler (if needed to get 48 kHz audio)

5. Audio Sink

- Sample Rate: 48000

6. Add visualization:

- QT GUI Frequency Sink (after RTL-SDR)
- QT GUI Frequency Sink (after audio)

Screenshot 2.1: Your complete FM receiver flowgraph.

[Insert screenshot]

Task 2.2: Tune to Different Stations

1. Run the flowgraph
2. Tune to at least 3 different FM stations
3. Record observations in the table below:

Station Frequency	Call Sign (if known)	Signal Strength	Audio Quality

Task 2.3: Observe FM Spectrum Characteristics

1. Zoom in on a single FM station in the frequency sink
2. Observe the occupied bandwidth

Screenshot 2.3: Spectrum of a single FM broadcast station showing bandwidth.

[Insert screenshot]

Question 2.1 (15 points)

- a) What is the approximate bandwidth occupied by an FM broadcast station (measure from your spectrum display)?
- b) The FCC allocates 200 kHz per FM station. Why is this more than the audio bandwidth (15 kHz)?
- c) Compare the spectrum of a station playing music vs. speech. What differences do you observe?

Your Answer:

[Write your answer here]

Task 2.4: Explore Stereo FM (Optional Bonus)

FM stereo uses a 19 kHz pilot tone and L-R difference signal at 38 kHz.

1. Add an **FFT** block after the FM demodulator
2. Look for the 19 kHz pilot tone and 38 kHz subcarrier

Screenshot 2.4: Spectrum showing stereo pilot tone (if visible).

[Insert screenshot]

Part 3: Frequency Deviation Measurement (20 points)

Task 3.1: Measure Frequency Deviation

The FM broadcast standard uses ± 75 kHz maximum deviation.

1. Observe the spectrum during loud audio passages
2. Observe the spectrum during quiet passages
3. Note how the occupied bandwidth changes

Question 3.1 (10 points)

- a) During loud audio, does the FM signal's occupied bandwidth increase or decrease?
- b) FM stations use "pre-emphasis" to boost high frequencies before transmission. Why is this done?
- c) What is the modulation index () for an FM station with 75 kHz deviation and 15 kHz audio bandwidth? Use: $\beta = \Delta f / f_m$

Your Answer:

[Write your answer here]

Task 3.2: Compare NBFM vs WBFM

Try receiving a narrowband FM signal (if available): - Public safety or amateur radio: 144-148 MHz or 440-450 MHz - NBFM uses ± 5 kHz deviation

Question 3.2 (10 points)

- a) What is the bandwidth difference between WBFM (broadcast) and NBFM?
- b) Why do mobile radios use NBFM instead of WBFM?

Your Answer:

[Write your answer here]

Part 4: WiFi Spectrum Observation (25 points)

Task 4.1: View 2.4 GHz WiFi Spectrum

Note: RTL-SDR typically covers up to ~ 1.7 GHz. For 2.4 GHz, you may need to: - Use a downconverter, or - Use a different SDR (HackRF, USRP), or - Observe the spectrum using `hackrf_sweep` or similar tool

If RTL-SDR cannot reach 2.4 GHz, complete this section using: 1. WiFi analyzer app on your phone, or 2. Spectrum screenshots from instructor materials

WiFi Channel Allocation

Channel	Center Frequency	Notes
1	2.412 GHz	
6	2.437 GHz	Common default
11	2.462 GHz	

Screenshot 4.1: 2.4 GHz WiFi spectrum showing multiple access points.

[Insert screenshot or describe observations]

Task 4.2: Identify WiFi Characteristics

Observe and record:

1. **Channel width:** _____ MHz
2. **OFDM subcarrier spacing visible?** Yes / No
3. **Approximate power level difference between channels:** _____ dB

Question 4.1 (15 points)

- a) Standard 802.11n WiFi channels are 20 MHz wide. Why don't adjacent channels (e.g., 1 and 2) interfere with each other if they're only 5 MHz apart?
- b) How many non-overlapping 20 MHz channels exist in the 2.4 GHz band?
- c) Modern 802.11ac/ax uses 80 MHz or 160 MHz channels in the 5 GHz band. What is the trade-off between wider channels and coverage?

Your Answer:

[Write your answer here]

Task 4.3: Observe WiFi Traffic Patterns

1. Watch the spectrum while:
 - Streaming video
 - No network activity
 - Downloading a large file
2. Note the difference in spectrum activity

Observations:

[Describe what you observed]

Part 5: Advanced Exploration (10 points)

Task 5.1: Explore Other Signals (Choose One)

Using your RTL-SDR, find and observe one of the following:

- ☐ **ADS-B aircraft signals** (1090 MHz)
- ☐ **NOAA weather satellites** (137 MHz)

- ☐ **Amateur radio** (144-148 MHz or 420-450 MHz)
- ☐ **Pager signals** (~929 MHz)
- ☐ **Weather radio** (162.4-162.55 MHz)

What signal did you find? _____

Screenshot 5.1: Spectrum of the signal you discovered.

[Insert screenshot]

Description: Describe the signal characteristics (bandwidth, modulation type if known, activity pattern).

[Write your description here]

Lab Summary

Key Concepts Learned

1. **FM Broadcasting:** ± 75 kHz deviation, 200 kHz channel spacing
2. **SDR Architecture:** RTL-SDR samples RF directly, software does demodulation
3. **WiFi Spectrum:** 20/40/80 MHz channels, OFDM modulation, overlapping channels
4. **Real-world signals:** Impairments, interference, varying signal strengths

Practical Skills Developed

- ☐ Built working GNU Radio flowgraph
 - ☐ Tuned and received FM broadcast signals
 - ☐ Analyzed RF spectrum characteristics
 - ☐ Identified different signal types in spectrum
-

Submission Checklist

- ☐ All screenshots inserted
- ☐ All questions answered
- ☐ All tables completed
- ☐ Flowgraph files (.grc) attached
- ☐ Document saved as PDF

Files to Submit: 1. This completed worksheet (PDF) 2. fm_receiver.grc (your FM receiver flowgraph) 3. Any additional flowgraphs created

Submit to Brightspace by due date.