


Illustration 4.4a Propulsion Converter



Key

PRC - Process Control

CLC - Converter Local Control

CCU - Converter Cooling Unit

PRE - Pre-charge Cubicle

DFE - Diode Front End

DCC - DC Capacitor

INV - Inverter

ILC - Inverter Local Control

AC OUT - AC Output Section

Propulsion Converter
Panel Arrangement