


THIS IS A WORK IN PROGRESS!



GPS will not work when FTDI TX wire is plugged  
FTDI cable should only be used for firmware upgrades (GPS off)  
Pull-down resistor on GPS\_TX might not be required.