



① Screen printing electrode pattern using Ag/AgCl as RE

② Prepare carbon cloth and Tailor the carbon cloth

③ Paste the cut carbon cloth to the working electrode position

④ Drop the sodium selective membrane liquid on WE