



- You can**
- listen to music using wireless Bluetooth stereo headphones or through the speakers on your phone
  - listen to music with your phone open or closed
  - use touch-sensitive buttons on the outside of your phone to control the music when your phone is closed

1. Press to access your music player.

2. Select songs to play from folders. Every song on your phone appears in **All**. Songs may not appear in all folders.

**Tip:** To play songs in random order, press **Options > Setup > Shuffle > On**.

3. To play a song, press .

**Tip:** To change the volume, press the volume keys on the side of the phone. To turn off the music player, press .

4. Use the navigation keys to control the music:

Pause/Play, press **Up**

Rewind, press and hold **Left** (for at least 2 seconds)

Fast Forward, press and hold **Right** (for at least 2 seconds)

Play previous song, press **Left** (within first five seconds)

Play next song, press **Right**

Restart song, press **Left** (after first five seconds)

Stop song, press **Down**

5. If you receive a call while music is playing, the song pauses, then resumes when the call ends.

**Tip:** To take the call, press **Answer**. To reject the call, press **Ignore**.

6. To use other phone features while playing music, press **Options > Hide**. To stop the hidden music player, press in the home screen.

**Tip:** To add a song to a playlist while it is playing, press **Options > Apply to > Playlist**.

7. Close the flip and use the visual keys on the flip cover to control the music:

Press to pause/play

Press to play the next song

Press to play the previous song

Press and hold to fast forward

Press and hold to rewind

To stop the music, press and hold the pause/play button.

**Tip:** To lock and unlock the touch sensitive keys, press and hold the Smart Key on the side of the phone.

