

Equipment Manual - Suggested Actions to Improve Uptime

1. Replace the agitator shaft seal with part #AGT-455 immediately after 300 operational hours to prevent leakage-related shutdowns.
2. Install the vibration monitoring kit (model VM-200) on Mixing Tank #1 to detect early bearing wear and schedule repairs before failure.