



PT5 WILL HAVE TO BE LOOPED BETWEEN THE TWO CONNECTORS.
26 PIN CONNECTOR DOES NOT HAVE ENOUGH PASSTHROUGH LINES

IGN WILL HAVE TO BE LOOPED BETWEEN THE TWO CONNECTORS.
THIS IS NOT REAL IGN ON BOLT, IT SHOULD NOT BE ROUTED TO THE CAR HARNESS

IGN_GND WILL ONLY CONNECT TO THE ADAPTER BOARD.
THIS WIRE IS REQUIRED ON CAN BASED IGNITION CARS TO PREVENT DRAIN FROM THE DIODE ON THE HARNESS
GND AND IGN_GND ARE CONNECTED TOGETHER ON THE ADAPTER BOARD

comma.ai
you can copy this!

9

TITLE: Bolt_Harness

Design by:

REV:

Date: 9/1/22 6:55 PM

Sheet: 1/1