



# AUDIO BUFFER

maybe not needed




# BREAKPOINT VOLTAGES

maybe precision resistors




# CV AND MANUAL MORPH CONTROL

investigate cheaper clamp solution





# CALCULATE DIFFERENCE WITH BREAKPOINT




# PRECISION RECTIFIERS

USE FAST OPAMP, UNDECIDED



# V2164 QUAD VCA MIXER AND BUFFER



# PULL DOWN AND CLAMP

