


## DRILL POINT FOR ELECTRONIC DEAD BOLT LOCKS

### SOLENOID LOCKS MANUFACTURED AFTER 01/01/1997

All measurements are taken from the center of the spindle. The diagram is for a lock mounted in the vertical down position. If the lock is facing in another direction, make the appropriate adjustments. If you do not know how the lock is mounted on the container, call the container manufacturer for additional information.

1. From the center of the spindle hole measure 1 1/4" toward the bolt and 1/2" left (counterclockwise).
2. Drill a 1/4" hole.
3. This will remove the side bar tip and should release the bolt.



**Drawing not to scale**