

Pin 35	12V Ignition	Red (1.0mm)	27
Pin 30	Fuel Pump Relay	Black (0.5mm)	38
Pin 24	Idle Valve	Brown	30
Pin 23	Lambda Signal	Pink	23
Pin 25	Ground**		
Pin 6	Ground*		
Pin 26	Trigger Signal	Red inside screen	24
Pin 13	Coolant Sensor	Purple	21
Pin 22	Air Sensor*	Grey/Blue	20
Pin 14	Injectors***	2 x White (0.5mm)	32,33

**** Connect these to same point as main MS Ground wires (Black 1.0mm)**

*** There are 2 injector drivers in the MIS ECU, but the GTV uses only one of them in its original wiring form, so leave Bank2 (green wires from MS) disconnected and select "Simultaneous" in constants page in MegaTune for injectors!

Please note:
None of this has been tested and it is strictly to be used at your own risk!
No warranty expressed or implied!
Check your wiring is the same as this drawing!!

