





SPDT



Model No.	Switching position		
TS-13	ON	NONE	ON
TS-13A	(ON)	NONE	ON
TS-14	ON	OFF	ON
Term. Comm.	2-3	open	2-1






TS-13-A1-2-BQ

DPDT




Model No.	Switching position		
TS-11	ON	NONE	ON
TS-12	ON	OFF	ON
Term. Comm.	2-3	5-6	open 2-1 5-4






TS-11-A1-2-BQ

HORISON RIGHT ANGLE

SPDT




Model No.	Switching position		
TS-13P	ON	NONE	ON
TS-13PA	(ON)	NONE	ON
TS-14P	ON	OFF	ON
Term. Comm.	2-3	open	2-1






TS-13P-A1-2-Q(-E)

DPDT




Model No.	Switching position		
TS-11P	ON	NONE	ON
TS-12P	ON	OFF	ON
Term. Comm.	2-3	5-6	open 2-1 5-4





TS-11P-A1-2-Q(-E)

VERTICAL RIGHT ANGLE

SPDT




Model No.	Switching position		
TS-13L	ON	NONE	ON
TS-13LA	(ON)	NONE	ON
TS-14L	ON	OFF	ON
Term. Comm.	2-3	open	2-1






TS-13L-A1-2-Q(-E)

DPDT



Model No.	Switching position		
TS-11L	ON	NONE	ON
TS-12L	ON	OFF	ON
Term. Comm.	2-3	5-6	open 2-1 5-4




TS-11L-A1-2-Q(-E)


VERTICAL SUPPORT BRACKET OPTION

(only apply the straight type terminal - Please modify the terminal option is "c" code)

S20



SPDT




TS-13-A1-2-CQ-S20

S25




SPDT




TS-13-A1-2-CQ-S25

S20



DPDT



TS-11-A1-2-CQ-S20