


USB Power

TYPE L →

AC Power 

Audio Extension  
↳

Reset  
Button



Speakers

A →  
LED →

B →  
LED →

Sensor Wires

LEDs

SD Card  
(Push in to remove!)

Power Switch  
Tail Kit

Spotlight Cable

Spotlight  
Fixture →

TYPE USA →

Spotlight

AC Power 

TYPE L →

Spotlight  
Power →

