


FLOATING DOMAIN

BUS DOMAIN

NOTE: U14 should have high bandwidth to avoid phase shift between current and voltage sensing.



- TODO: Revisit voltage divider resistors values (also reduce current)
- TODO: Change full scale to 4A.
- TODO: Revisit bypass capacitors
- TODO: Add test points

PWM CURRENT/VOLTAGE SENSOR