


Mounting Holes



GND ← MH2

GND ← MH3

Internal Bootstrapping Resistors	
MTDI/GPI012:	Pull-Down
GPI00:	Pull-Up
GPI02:	Pull-Down
GPI04:	Pull-Down
MTDO/GPI015:	Pull-Up
GPI05:	Pull-Up

Voltage of Internal LPO(VDD_S00)				Boostrapping Pins Settings	
Pin	Default	3.3V	1.8V		
IPD12/NTDI	Pull-Up/Down	0	0		
Boostrapping Mode					
Pin	Default	SPI Flash Boot	Download Boot		
IPD0	Pull-Up	1	0		
IPD0	Pull-Down	Don't-care	0		
IPD02	Pull-Up	0	0		
Debugging Log on UART0 During Booting					
Pin	Default	UART0	UART0 Silent		
IPD0	Pull-Up	UART0	UART0 Silent		
IPD05/NTD0	Pull-Up	UART0	UART0 Silent		
IPD05/NTD0	Pull-Up	UART0	UART0 Silent		
Timing of Sdio Slave					
Pin	Default	Falling-edgeOutput	Rising-edgeinput	Rising-edgeinput	Rising-edgeinput
IPD05/NTD0	Pull-Up	0	1	0	0
IPD05/NTD0	Pull-Up	0	1	0	0
IPD05	Pull-Up	0	1	0	1

OLIMEX
<https://www.olimex.com>
OLIMEX LTD.



Sheet: /
 File: ESP32-EVB_Rev_H.sch
Title: ESP32-EVB
 Size: A2 Date: 2019-04-17 Rev: H
 KiCad E.D.A. kicad 5.1.0-rc2-unknown-036be7d80ubuntu16.04.1 Id: 1/1